


# Table of Contents

**Power ON** ..... 1



# Power ON

- ensure the box is powered off correct like described above, make sure all switches are in a safe position (off/safe)
- move power switch up to on position → red light above power switch turns on
- insert key
- turn key right to left position → red light above key switch turns on



From:  
<https://wiki.raketenclub.de/> - **RaketenClub**

Permanent link:  
[https://wiki.raketenclub.de/rc/prj/startbox/v1.0/50\\_proc/20\\_power\\_on](https://wiki.raketenclub.de/rc/prj/startbox/v1.0/50_proc/20_power_on)

Last update: **2020/09/07 23:57**

